


## Note #225 - Type #5 Factory Keyless Entry Interface



- The Type #5 Factory Keyless Entry Interface is a universal type that will interface with any factory keyless entry system which provides a driver's door priority unlock by remote. This means that the factory remote will unlock the driver's door first when the unlock button is pressed, then, after the driver's door is unlocked, a second press of the remote unlock button will unlock all of the doors.

- The 6-pin harness of the AL-100, AL-100-H, and VIP-4000 contains the principal wires which are wired into the factory keyless entry door lock system to allow the unit to arm and disarm from the factory keyless entry remote.

**CONNECTION:** The diagram above shows how to connect the 6-pin harness from the AL-100, AL-100-H, or VIP-4000 to a factory keyless entry using the Type #5 system. Notice that a connection to the switch input wires is not required in this system. The Gray wire is connected to the driver door unlock output, the Brown wire is connected to the all door unlock output, and the Pink wire is connected to the lock output from the keyless entry module / door lock control module. The Green and Blue wires are not used in this system.